## Product Guide Sheet Battery Changer Insulated (FSBI)

To use the attachment, ensure that the truck seat, battery cover etc. are tilted out of the way and that there are no obstructions to prevent the battery being lifted. Raise the forks until the attachment is above battery level, allowing clearence to fit the hooks. Drive the truck forwards so that the attachment is between the battery and the overhead guard and positioned centrally along the battery length.

When the attachment is in place, fit the hooks one through each hole in the outer steel casing. In the event of only one hole being avaliable in each end of the casing fit 2 hooks through each end, if hole diameters permit. Failing this ensures that the free legs are back-hooked out of the way. Position hooks to face outwards from the battery.

Our Insulated
Battery Beam is
designed to remove
and replace fork
truck batteries
simply and without
damage,
incorporating non
conductive lifting

brothers for added



safety. Slide and clamp onto truck forks. Made to suit individual batteries.

Model Ref.	Capacity	A (Hole Ctrs)	B (Battery Width)	C (Battery Length)	H (Hole Dia)	E (Fork Spread)
FSBI-1	1000Kg					307mm
FSBI-2	2000Kg					307mm



## Ordering Information:

- ✓ Truck Capacity
- ✓ Fork Width & Thickness
- ✓ Battery Weight
- ✓ Dimensions A. B. C and H

## Max Fork Size 140 x 50mm

